

ALUMINUM GROUP OUTSERT[®] SIGNAGE

90° WALL MOUNT- INSTALLATION INSTRUCTION

Screw holes have been drilled in the back of the casing strip. Use these holes as a template to mark the wall surface for drilling. Make sure channel is exactly vertical using a small level and that the "V" groves are in line with each other when the sign is installed. This centers the casing block assembly in the casing strip so the casing block, as well as the entire sign, is centered in the casing strip. Drill a 3/16" hole into the drywall, brick or cement for the anchors (provided). Install the anchors flush with the wall surface. #10-12 x 1" screws (provided) are used to secure the casing strip to the wall. Slide the casing block into the casing strip, The set screws may have to be backed out a little to allow the block to slide down. When the casing block is flush at the top and bottom, tighten the set screws using a 1/16" allen wrench provided.

