

ALUMINUM GROUP OUTSERT® SIGNAGE CEILING MOUNT 2 - INSTALLATION INSTRUCTION

Ceiling signs are shipped with 20 feet of heavy gage suspension wire. This wire loops through the top of the sign and is connected into the ceiling at each end. Remove the end trim plates with a small phillips screw driver. Place the wire into the slotted trough at the top of the backer assembly. Slide the wire clamping bar in the trough over the wire at each end. These wire clamping bars are held in place with two set screws for each bar that must be tightened down securely to assure the wire is clamped in place. The bars should be positioned equal distance from each end of the sign. Replace the end trim plates.

The ceiling wire grip consists of a cap that gets affixed to the ceiling with a screw (see drawings below), the body that houses the cable collar and the cable collar that terminates the wire. The set screw in the cable collar **must be tightened securely** to support the sign. The cap and body of the wire grip screw together to complete the installation.

Wood ceiling: A wood or sheet metal screw can be used and must have at least 1/2" thread engagement.
Drywall ceiling: Drill a hole large enough for inserting the wing nut and tighten

