

ALUMINUM GROUP OUTSERT® SIGNAGE SCREW MOUNT - INSTALLATION INSTRUCTION

Screw holes have been drilled in the backer assembly of the sign. The message tiles must be removed to expose the mounting screw holes. Use a level and these holes as a template to mark the surface for drilling. #4 x 1" screws (provided) are used to secure the sign (NOTE: DO NOT OVER TIGHTEN SCREWS). Smaller signs may only require (2) screws. For drywall or brick, anchors (provided) must be used. A 3/16" hole is recommended for the anchors.

