

OUTSERT® SIGNAGE TAPE MOUNT - INSTALLATION INSTRUCTION

TAPE MOUNT OPTION: The door or smooth wall surface in the area the tape pads contact should be clean. Lightly mark the spot for the sign by using a level and the outside of the sign as a template. Remove the protective cover of the tape pads on the back of the sign. **We recommend adding silicone adhesive to the back of the sign for extra holding strength (silicone adhesive must be added when installing on a vinyl wall covering).** The message tiles should be removed to apply pressure on the tape pad areas. Position and press firmly especially in the tape pad areas.

GLASS MOUNT OPTION: Refer to the tape mount instructions for mounting. An adhesive mask is included for the back side of the glass directly behind the sign. If the vinyl mask is mis-applied, simply peel off and reapply.

