


DOT-DASH SIGNAGE / INSTALLATION TOP-OF-PANEL MOUNT - METAL

Clean top cap surface with a solution of isopropyl alcohol and water.

Note the plaque placement in the dot and its position to the panel termination before installing the bracket.



Remove protective adhesive cover from the back of the bracket, position and press firmly on the entire surface of the bracket. *Allow a minimum of 24 hours for the adhesive to set.*



The back half of the dot is attached to the bracket with a #8-32 x 5/8" flat head screw. A 3/32" allen wrench (provided) is required to loosen or tighten the screw. NOTE: by rotating the dot with this screw loose the plaque can be positioned above or below the dot as shown..

The screw holding the back half of the dot to the bracket *must be firmly tightened* to hold the dot and the plaque in desired position.

Hold plaque against shoulder of dot and turn cap and washer tightly against plaque, (rubber side of washer against

