

ALUMINUM GROUP OUTSERT[®] SIGNAGE TOP PANEL/AVENIR- INSTALLATION INSTRUCTION

Remove slide-on/off panel top cap. The screws holding the continuous clip must be loosened to expose the top of the panel. Bracket fits over the top surface of the panel on either side of the panel and under the continuous clip. Tighten the continuous clip back down clamping the bracket between the panel and the continuous clip. Slide the top cap back onto the panel.

