

ALUMINUM GROUP OUTSERT[®] SIGNAGE TOP PANEL/PLACES- INSTALLATION INSTRUCTION

Remove snap-on/off panel top cap. Bracket fits over the top lip of the panel on either side of the panel. Snap the top cap back on panel. The top cap will hold the bracket in place and the bottom edge of the top cap will hold the bracket flat against the face of the panel.

