

ALUMINUM GROUP OUTSERT[®] SIGNAGE PIN MOUNT - INSTALLATION INSTRUCTION

The two pins installed at the back side of the sign flex from a vertical position to approximately 30 degrees out away from the back. This helps both in the installation and in having the sign lay flat against the fabric surface. A pin mounting tool (supplied) is used to hold the pins out in the 30 degree installation position at the same time as the sign is being aligned and pinned into the fabric. Lower and remove the pin mounting tool after the pins enter the fabric.

