

# ALUMINUM GROUP OUTSERT<sup>®</sup> SIGNAGE DESK MOUNT - INSTALLATION INSTRUCTION

The end cap on either side of the desk sign can be removed by simply pulling off. The tiles (or paper insert) on any of the three sides can then be changed by sliding the tile (or paper) out and replacing the end cap.

