

A MAGNETIC WINDOW can cover an entire sign or any portion of a sign, due to this being a single unit that slides into the module assembly. Neodymium magnets, hidden behind the top trim, secure the lens. Opening the lens requires a suction cup tool.

Paper insert, graphic or clear acetate insert can be simply “dropped” in or pulled out.

Closing the lens is easily done, by allowing the magnets to snap it back into place.

